

**4- WAY-44235 ROUND ROCKER SWITCH (DASH, FRONT, REAR, SIREN)**

*Install switches per manufacturer recommendations to be accessible to the driver*

**1- CODE3 920-10TH PLUG-IN PLAY HEADLIGHT FLASHER 11-15**

*The flasher will be installed to manufacturer recommendations which are a plug in assembly.*

**1- Code 3 SV77MCTH15-Supervisor-TS-Multicolor-B/W**

*Install interior bar per manufacture recommendation in the front windshield.*

**1- FENIEX -D-20809-B COBRA 800 BLUE (REAR WINDOW)**

*Install interior bar per manufacture recommendation in the rear windshield.*

**2- FENIEX-D-09010 COBRA HEADLINER BRKT**

*Install per manufacturer recommendations*

**6- FENIEX-D-12009B COBRA T6 BLUE (2 SIDE BACK WINDOWS and 4 in grill)**

*To be installed to manufacturer recommendations rear side windows*

**6- FENIEX-D-04309 COBRA ROTATING BRACKET**

*Install per manufacturer recommendations*

**1-FENIEX-D-09010 COBRA HEADLINER BRKT (GRILL MOUNT)**

*To be installed to manufacturer recommendations behind the front grill of the Tahoe*

**1- STREAMLIGHT STINGER LED LIGHT**

*To be installed by at discretion upon installation of equipment*

**2- FENIEX-H-2209WW - CANNON 120 WHITE/ WHITE ( MOUNT ON REAR LIFT GATE FOR WORK LIGHT)**

*Install per manufacturer recommendation*

**1- WAY-44250 TOGGLE SWITCH (INSTALL IN HANDLE OF LIFT GATE FOR WORK LIGHT)**

*Install per manufacturer recommendation*

**4- FENIEX- H-2209BW CANNON 120 BLUE / WHITE (CORNERS)**

*Install per manufacturer recommendation in front corner lights ensuring proper seal. To be installed in headlights and taillights*

**2- CODE3 MR6FM-BW MR6 BLUE/WHITE SURFACE/FLUSH MOUNT ( MOUNTED IN LIFTGATE WHEN GATE IS OPEN)**

*Install per manufacturer recommendation*

**2- CODE3 MR6FMKIT -GROMMENT FOR MR6 FLUSHMOUNT**

*Install per manufacturer recommendation*

**1 -CARSON SA-361-20 DEFENDER SIREN**

*Install per manufacturer recommendation*

**1- FENIEX-S-2009 TRITON 100W SPEAKER**

*Install per manufacturer recommendation behind front grille*

**1- PHANTOM ELITE UHF ANTENNA**

*Installed behind the front grill of the vehicle*

**2- MOTOROLA-17CO MOTOROLA 17FT CO-AXIAL CABLE**

*Cable to be run from antenna location to the radio not to be seen by occupants in the vehicle.*

**2- MOTOROLA FRONT MOUNT POWER CABLE**

*Cable to be installed from power location to the radio not to be seen by occupants in the vehicle.*

**1- MOTOROLA SPEAKER IGNITION PLUG**

*Cable to be installed from power location to the radio not to be seen by occupants in the vehicle.*

**2- COAXIAL L BRACKETS**

*Install with lights per manufacturer recommendations*

**1- PHANTOM 800 ANTENNA**

*Installed behind the front grill of the vehicle*

**1- STOP STICK- 9FT**

*Place stop sticks inside the rear of the vehicle. Department will install*

**1- 1 - TUFLOC 36-009 SUV WIDE BOX**

*Installed in the rear cargo area of the vehicle and secured to the vehicle by manufacture recommendations*

**1- Installation of the Motorola XLT 5000 and CM300 Radio**

*Install above said equipment inside the vehicle center console. With the installation, create a faceplate for all equipment in the center console to provide a smooth background surrounding the faceplate with speaker mounted not to be seen from passengers in the vehicle*

**LABOR TO INSTALL ABOVE & CUSTOMER  
SUPPLIED RADIO**