

4- WAY-44235 ROUND ROCKER SWITCH (DASH, FRONT, REAR, SIREN)

Install per manufacturer recommendations on front dash accessible to the driver

1- CODE3 920-10TH PLUG-IN PLAY HEADLIGHT FLASHER 11-15

The flasher will be installed to manufacturer recommendations which are a plug in assembly.

1- Code 3 SV77MCTH15-Supervisor-TS-Multicolor- B/W both sides

Install interior bar per manufacture recommendation in the front windshield.

1- FENIEX -D-20809-B COBRA 800 BLUE (REAR WINDOW)

Install interior bar per manufacture recommendation in the rear windshield.

2- FENIEX-D-09010 COBRA HEADLINER BRKT

Install per manufacturer recommendations

4- FENIEX-D-12009B COBRA T6 BLUE (SIDE BACK WINDOW & GRILL)

To be installed to manufacturer recommendations behind the front grill of the Tahoe and rear side windows

4- FENIEX-D-04309 COBRA ROTATING BRACKET

Install per manufacturing recommendations

2- FENIEX-H-2209WW - CANNON 120 WHITE/ WHITE (MOUNT ON REAR LIFT GATE FOR WORK LIGHT)

Mount on rear lift gate of Tahoe

1- WAY-44250 TOGGLE SWITCH (INSTALL IN HANDLE OF LIFT GATE FOR WORK LIGHT)

Mount on rear lift gate of Tahoe in handle area

4- FENIEX- H-2209BW CANNON 120 BLUE / WHITE (CORNERS)

To be installed per manufacturer recommendations

2- CODE3 MR6FM-BW MR6 BLUE/WHITE SURFACE/FLUSH MOUNT

Mounted in lift gate when gate is open

2- CODE3 MR6FMKIT -GROMMENT FOR MR6 FLUSHMOUNT

To be installed per manufacturer recommendations

1 -CARSON SA-361-20 DEFENDER SIREN

Install per manufacturer recommendation

1- FENIEX-S-2009 TRITON 100W SPEAKER

Install inside grill on front of vehicle

1- MOTOROLA-17CO MOTOROLA 17FT CO-AXIAL CABLE

Cable to be ran from antenna location to the radio not to be seen by occupants in the vehicle.

1- MOTOROLA FRONT MOUNT POWER CABLE

Power cable to run from a fuse power source if applicable to the radio not to be seen by occupants in the vehicle

1- MOTOROLA SPEAKER IGNITION PLUG

Ignition plug to be ran from a fused power source if applicable to the vehicle manufacturer console where the radios are to be installed.

1- COAXIAL L BRACKETS

Install with lights per manufacturer recommendations

1- PHANTOM 800 ANTENNA

Installed behind the front grill of the vehicle

1- STOP STICK- 9FT

Leave in back of the vehicle inside lock box

**1- TUFLOC 36-009 SUV WIDE BOX (COMBINATION
W/ KEY OVERRIDE)**

Installed in the rear cargo area of the vehicle and secured to the vehicle by manufacture recommendations

1- STR-20702 STREAMLIGHT 20702 SL-20L FLASHLIGHT DC

To be installed in a location on the driver side which is accessible to the driver without interfering with the driver? Must be attached to a power source for charging.

1- Installation of the Motorola XLT 5000 Radio,

Install above said equipment inside the vehicle center console. With the installation, create a faceplate for all equipment in the center console to provide a smooth background surrounding the faceplate with speaker mounted not to be seen from passengers in the vehicle

**LABOR TO INSTALL ABOVE & CUSTOMER
SUPPLIED RADIO**