

2016- INVESTIGATOR TAHOE SPEC # 45 1 OF 4

**4- WAY-44235 ROUND ROCKER SWITCH (DASH, FRONT, REAR,
SIREN NOT TO BE SEEN BY OCCUPANTS OF THE VEHICLE)**

Install per manufacturer recommendations on front dash accessible to the driver

**1- CODE3 920-10TH PLUG-IN PLAY HEADLIGHT
FLASHER 11-15**

The flasher will be installed to manufacturer recommendations which are a plug in assembly.

1- Code 3 SV77MCTH15-Supervisor-TS-Multicolor- B/W Both Sides

Install interior bar per manufacture recommendation in the front windshield.

**1- FENIEX -D-20809-B COBRA 800 BLUE (REAR
WINDOW)**

Install interior bar per manufacture recommendation in the rear windshield.

2- FENIEX-D-09010 COBRA HEADLINER BRACKET

Install per manufacturer recommendations

2016- INVESTIGATOR TAHOE SPEC # 45 2 OF 4

6- FENIEX-D-12009B COBRA T6 BLUE (SIDE BACK WINDOW & 4-GRILL)

To be installed to manufacturer recommendations behind the front grill of the Tahoe and rear side windows

6- FENIEX-D-04309 COBRA ROTATING BRACKET

Install per manufacturer recommendation

2- FENIEX-H-2209WW - CANNON 120 WHITE/ WHITE (MOUNT ON REAR LIFT GATE FOR WORK LIGHT)

Install per manufacturer recommendation

1- WAY-44250 TOGGLE SWITCH (INSTALL IN HANDLE OF LIFT GATE FOR WORK LIGHT)

Install per manufacturer recommendation with fused power source if needed.

2- FENIEX- H-2209BW CANNON 120 BLUE / WHITE (CORNERS)

Install per manufacturer recommendation in rear corner lights ensuring proper seal.

1- STR-20702 STREAMLIGHT 20702 SL-20L FLASHLIGHT DC

To be installed in a location on the driver side which is accessible to the driver without interfering with the driver? Must be attached to a power source for charging.

2016- INVESTIGATOR TAHOE SPEC # 45 3 OF 4

2- CODE3 MR6FM-BW MR6 BLUE/WHITE SURFACE/FLUSH MOUNT (MOUNTED IN LIFTGATE WHEN GATE IS OPEN)

Install per manufacturer recommendation

2- CODE3 MR6FMKIT -GROMMET FOR MR6 FLUSHMOUNT

Install per manufacturer recommendation

1 -CARSON SA-361-20 DEFENDER SIREN

Install per manufacturer recommendation

1- FENIEX-S-2009 TRITON 100W SPEAKER

Install per manufacturer recommendation behind front grille

2- MOTOROLA-17CO MOTOROLA 17FT CO-AXIAL CABLE

Cable to be run from antenna location to the radio not to be seen by occupants in the vehicle.

2- MOTOROLA FRONT MOUNT POWER CABLE

Power cable to run from a fuse power source if applicable to the radio not to be seen by occupants in the vehicle

2016- INVESTIGATOR TAHOE SPEC # 45 4 OF 4

1- MOTOROLA SPEAKER IGNITION PLUG

Ignition plug to be ran from a fused power source if applicable to the vehicle manufacturer console where the radios are to be installed.

2- COAXIAL L BRACKETS

Install with lights per manufacturer recommendations

1- PHANTOM 800 ANTENNA

Installed behind the front grill of the vehicle

1- PHANTOM ELITE UHF ANTENNA

Installed behind the front grill of the vehicle

1- STOP STICK- 9FT

Leave in back of the vehicle inside lock box

**1- TUFLOC 36-009 SUV WIDE BOX (COMBINATION
W/ KEY OVERRIDE)**

Installed in the rear cargo area of the vehicle and secured to the vehicle by manufacture recommendations

1- Installation of the Motorola XLT 5000 Radio and CM300

Install above said equipment inside the vehicle not to be seen by occupants of the vehicle.

**LABOR TO INSTALL ABOVE & CUSTOMER
SUPPLIED RADIO**