2016 SGT. TAHOE SPEC. (2 VEHICLES) 1 of 6

1- Code 3 SV77MCTH15-Supervisor-TS-Multicolor-R/W one side-B/W other side

Install with lights per manufacturer recommendations

1- FENIEX-D-50815BRA APOLLO 800 EXTERNAL MOUNT BA, BA, BA, BA, RA, RA, RA, RA (REAR WINDOW)

Install with lights per manufacturer recommendations

2- FENIEX-D-09010 COBRA HEADLINER BRKT

Install per manufacturer recommendation

1- COD-920-10TH CODE3 920-10TH PLUG-IN PLAY HEADLIGHT FLASHER 11-15

Install per manufacturer recommendation

- 10- FENIEX-D-12099RB COBRA T6 RED-BLUE
- 2- REAR TAG,
- 2- SIDE PUSH BUMPER,
- 2- FORWARD PUSH BUMPER-R.BKT
- 2-FRONT RUNNING BOARD-R.BRKT
- 2- REAR RUNNING BOARD-R.BRKT

Install with lights per manufacturer recommendations

2- FENIEX-D-12009BW COBRA T6 BLUE /WHITE (MIDDLE RUNNING BOARD-R.BRKT)

Install with lights per manufacturer recommendations

8- FENIEX -D-04309 COBRA ROTATING BRACKET

Install per manufacturer recommendation

2016 SGT. TAHOE SPEC. (2 VEHICLES) 2 of 6

2- FENIEX-H-2209WW CANNON 120 WHITE/ WHITE (MOUNT ON REAR LIFT GATE FOR WORK LIGHT)

Install per manufacturer recommendation

1- WAY-44250 TOGGLE SWITCH (FOR WORK LIGHT)

Install per manufacturer recommendation

1- SOUND OFF-ECVDMLTAL00 LED DOME LIGHT W/ RED LED NIGHT LIGHT (MOUNTS ABOVE CONSOLE)

Install per manufacturer recommendation

1- Code 3 Z3 100/200 WATT PROGRAMMABLE LIGHT CONTROL SIREN

Install per manufacturer recommendations in the center console for the control head, and operation box ex install in rear of the Tahoe where not be exposed to damage from equipment to be stored

1- CODE3 3450 BANSHEE DUAL TONE & LOW FREQUENCY SIREN AMP

Install per manufacturer recommendations, install in rear of the Tahoe where not be exposed to damage from equipment to be stored

2- CODE3-C3100CH15 100W SPEAKER W/ 2015+ TAHOE BRKT

Installed and wired to manufacturer recommendations. Installed behind the grille if allowable room.

2016 SGT. TAHOE SPEC. (2 VEHICLES) 3 of 6

1-JOTTO-425-6268 TAHOE 15+ CONSOLE W/ LOCKING LID (20" FP / 28" FLOOR PLATE)

Install per manufacturer recommendation

1- JOTTO-425-3704 DUAL INTERNAL CUPHOLDER

Install per manufacturer recommendation

3- 12 volt plugs mounted in the Jotto desk face plate to be attached to the Jotto Desk console.

Install this plate on the Jotto desk console with other equipment

1- JOTTO 425-5542/5182 CONSOLE SIDE MOUNT LAPTOP STAND (GAMBER/ KODIAK PLATES)

Install to console on the right side per manufacturer recommendations

1- JOTTO 475-0861 15+ TAHOE WINDOW ARMOR (BAR STYLE)

Install to both rear windows.

1- JOTTO-475-0865 SPACE CREATOR HIGH SECURTIY/ HIGH VISIBILITY - 2015 TAHOE

Install per manufacturer recommendations

1- JOTTO-475-0888 HIGH SECURITY EXTENSION PANEL 2PC 2015 + TAHOE

Install per manufacturer recommendation

1- JOTTO-475-0988 15+ TAHOE REAR CARGO BARRIER – UPPER POLY

Install per manufacturer recommendation

2016 SGT. TAHOE SPEC. (2 VEHICLES) 4 of 6

1- GAMBER JOHNSON 7160-0006 ARMREST PRINTER MOUNT FOR PENTAX MOBLIE PRINTERS

Install to the center console rear to be accessible to the officer

1- GAMBER JOHNSON 7160-0526-02 GETAC B300 DOCKING STATION W/ DUAL RF (TNC)

Install to the Gamber side mount stand

2- MOTOROLA FRONT MOUNT POWER CABLE

Cable to be run from antenna location to the radio in the center console not to be seen by occupants in the vehicle

1- MOTOROLA SPEAKER IGNITION PLUG

Cable to be installed from power location to the radio not to be seen by occupants in the vehicle.

2- MOTOROLA -17CO MOTOROLA 17FT CO-AXIAL CABLE

Cable to be installed from the antenna to the radio .

1- PHANTOM ELITE UHF ANTENNA

Installed behind the front grill of the vehicle

1- PHANTOM 800 ANTENNA

Installed behind the front grill of the vehicle

1- TUFLOC 36-009 SUV WIDE BOX

Install in the rear cargo area of the vehicle and secure it per manufacturer recommendations.

2016 SGT. TAHOE SPEC. (2 VEHICLES) 5 of 6

1- STOP STICK 9FT

Place stop sticks in the rear Tufloc box. Install stop sticks on the back gate not to interfere with the equipment box

1- STREAMLIGHT 20702 SL-20L FLASHLIGHT DC

Install per manufacturer recommendations. Flashlight should be installed on the front security cage between the front seats to be accessible to the officer.

1- WATCH GUARD VISTA - BODY CAM

Place stop sticks in the rear Tufloc box. Not to be installed in vehicle.

1- WATCH GUARD 4RE IN CAR CAMERA (Install GPS on front dash)

Install per manufacturer recommendation

1- AA-728 DUAL BAND MINI MAGNETC MOUNT ANTENNA (Use extension cable to install antenna on front dash)

Install the antenna on the front passenger dash board for maximum reception with wiring ran from the antenna to the docking station.

1- US GLOBAL BU-353-S4 (Use extension usb cable to install on front dash

Install the antenna on the front passenger dash board for maximum reception with wiring ran from the antenna to the docking station.

1- GI-38737 2015 TAHOE CENTER ONLY PUSH BUMPER

Install per manufacturer recommendation

2016 SGT. TAHOE SPEC. (2 VEHICLES) 6 of 6

1- Installation of the Motorola XLT 5000 Radio and CM 300

Install above said equipment inside the vehicle Jotto Console.

LABOR TO INSTALL ABOVE & CUSTOMER SUPPLIED 2 RADIOS